



**LANGEOHREN**

For more information

<http://www.langeohren.cn>



**LANGEOHREN**

# LONDON S

USER MANUAL

用户手册




# LANGEOHREN


---

# 产品信息


型号:LONDON S



# 开始使用



电量指示灯




充电口

开机/关机




## 初次配对



开机后未连接, 超过10分钟后将自动关机;  
在蓝牙连接状态下无任何操作, 30分钟后将自动关机。

## 基本操作



左声道



右声道




两台同款音箱开机, 先按一下其中一台音箱的蓝牙键,  
后再按两下另一台音箱的蓝牙键, 两台音箱同时发声,  
表示两台音箱已互相连接。

断开连接




清除连接设备




(有“嘟嘟”三声)红白灯同时闪三下


取消拨号/挂断/接听来电



拒接来电




## AUX线使用



使用AUX线同时连接音箱和设备,可自动切换到AUX模式

## LED指示灯

充电中 LED为红灯  
充电完毕为白灯




## 性能

防水等级IPX7



双声道



可单独或同时使用

## 电量



低电量提示: 每隔60S红灯闪一次, 每隔5分钟声音提示



自动关机, 请给音箱充电

## 总续航时间

50%音量播放音乐



= 14H

音箱充电时间



⌚ 2H

## 保修卡

感谢您选购LANGE OHREN(兔小诺)蓝牙音箱,当您在使用过程中出现任何非人为损坏性能故障时,将享有自收货之日起:7天包退,15天包换,1年保修的政策(以下简称“三包政策”)。

### ● 三包政策服务内容:

- 1.自收货之日起7日内,用户需要退货的,确保所收到的商品完好,产品包装和配件齐全,无人为损坏性能和外观受损,可根据购买凭证一次性退款,或者更换同型号同规格产品。(7日无理由退货,用户需要承担运费)
- 2.自收货之日第8日至15日内,产品出现无人为造成的性能故障,可根据购买凭证更换同型号同规格产品。
- 3.在一年保修期内,产品出现无人为造成的性能故障,请用户凭此保修卡和购物凭证与销售商取得联系,享有免费维修。

### ● 以下情况不属于三包政策服务内容:

- 1.自行拆卸造成的损坏;
- 2.因跌落摔坏、泡水、碰撞损坏等人为因素;
- 3.无保修卡、无购买凭证和故意修改凭证;
- 4.已经超过保修期;
- 5.因不可抗力造成的故障或损坏;

### ● 产品信息表:

|        |  |      |  |
|--------|--|------|--|
| 产品名称   |  | 机 型  |  |
| 产品条码   |  | 机身编号 |  |
| 购买凭证   |  | 凭证编号 |  |
| 购买日期   |  | 收货日期 |  |
| 用户姓名   |  | 联系电话 |  |
| 销售商    |  |      |  |
| 销售商联系人 |  | 联系电话 |  |

## 电子信息产品有毒有害物质清单

| 部分名称    | 有毒有害物质或元素 |       |       |           |           |             |
|---------|-----------|-------|-------|-----------|-----------|-------------|
|         | 铅(Pb)     | 汞(Hg) | 镉(Cd) | 六价铬(Cr6+) | 多溴联苯(PBB) | 多溴联苯醚(PBDE) |
| 印刷电路板组件 | ×         | ○     | ○     | ○         | ○         | ○           |
| 塑料      | ○         | ○     | ○     | ○         | ○         | ○           |
| 金属      | ×         | ○     | ○     | ○         | ○         | ○           |
| 电池      | ×         | ○     | ○     | ○         | ○         | ○           |
| 配件      | ×         | ○     | ○     | ○         | ○         | ○           |

本表格依据SJ/T11364的规定编制。

○:表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。

×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。



## 提示

- 1.使用产品前请仔细阅读本用户手册并请妥善保管;
- 2.首次使用,请先将本产品充满电;
- 3.如果产品长期(超过1个月)不使用,请对其充电;
- 4.必须选择正规厂家生产的经过第三方权威机构认证的充电线和电源适配器。

## 警告


- 1.请勿以任何理由拆除、维修和改装音响,否则可能会导致起火、电子击穿甚至彻底损坏本产品;
- 2.请勿将设备置于温度过低或过高( $-10^{\circ}\text{C}$ 以下或 $50^{\circ}\text{C}$ 以上)的环境中;
- 3.请勿在雷暴天气下使用该设备,雷暴可导致设备工作不正常,并增加触电的危险;
- 4.请勿用油及其它挥发性液体擦拭本产品;
- 5.本产品内含锂电池,禁止拆解、撞击、挤压或投入火中。若出现鼓胀,请勿使用。

# 合格证

本产品  
经检验合格准予出厂

## 產品信息

型號: LONDON S



①

加音量

②

暫停/播放

③

減音量

④

開/關機鍵

⑤

藍牙鍵

⑥

AUX綫接口


⑦

Type-C口

## 開始使用



電量指示燈




充電口

開機/關機



## 初次配對



開機後未連接，超過10分鐘後將自動關機；  
在藍牙連接狀態下無任何操作，30分鐘後將自動關機。

左聲道




右聲道



兩臺同款音箱開機，先按一下其中一臺音箱的藍牙鍵，  
後再按兩下另一臺音箱的藍牙鍵，兩臺音箱同時發聲，  
表示兩臺音箱已互相連接。


## 基本操作



斷開連接




清除連接設備




(有“嘟嘟嘟”三聲)紅白燈同時閃三下


取消撥號/挂斷/接聽來電



拒接來電




## AUX綫使用



使用AUX綫同時連接音箱和設備，可自動切換到AUX模式

## LED指示燈

充電中LED為紅燈  
充電完畢為白燈




## 性能

防水等級IPX7



雙聲道



可單獨或同時使用

## 電量



低電量提示: 每隔60S紅燈閃一次, 每隔5分鐘聲音提示



<5% 自動關機, 請給音箱充電

## 總續航時間

50%音量播放音樂



= 14H

音箱充電時間



⌚ 2H

## 保修卡

感謝您選購LANGEORHREN(兔小諾)真無線耳機，當您在使用過程中出現任何非人為損壞性能故障時，將享有自收貨之日起：7天包退，15天包換，1年保修的政策(以下簡稱“三包政策”)。

### ● 三包政策服務內容：

- 1.自收貨之日起7日內，用戶需要退貨的，確保所收到的商品完好，產品包裝和配件齊全，無人為損壞性能和外觀受損，可根據購買憑證一次性退款，或者更換同型號同規格產品。(7日無理由退貨，用戶需要承擔運費)
- 2.自收貨之日第8日至15日內，產品出現無人為造成的性能故障，可根據購買憑證更換同型號同規格產品。
- 3.在一年保修期內，產品出現無人為造成的性能故障，請用戶憑此保修卡和購物憑證與銷售商取得聯繫，享有免費維修。

### ● 以下情況不屬於三包政策服務內容：

- 1.自行拆卸造成的損壞；
- 2.因跌落摔壞、泡水、碰撞損壞等人為因素；
- 3.無保修卡、無購買憑證和故意修改憑證；
- 4.已經超過保修期；
- 5.因不可抗力造成的故障或損壞；

### ● 產品資訊表：

|        |  |      |  |
|--------|--|------|--|
| 產品名稱   |  | 機型   |  |
| 產品條碼   |  | 機身編號 |  |
| 購買憑證   |  | 憑證編號 |  |
| 購買日期   |  | 收貨日期 |  |
| 用戶姓名   |  | 聯系電話 |  |
| 銷售商    |  |      |  |
| 銷售商聯系人 |  | 聯系電話 |  |

## 電子資訊產品有毒有害物質清單

| 部分名稱    | 有毒有害物質或元素 |       |       |           |           |             |
|---------|-----------|-------|-------|-----------|-----------|-------------|
|         | 鉛(Pb)     | 汞(Hg) | 鎘(Cd) | 六價鉻(Cr6+) | 多溴聯苯(PBB) | 多溴聯苯醚(PBDE) |
| 印刷電路板組件 | ×         | ○     | ○     | ○         | ○         | ○           |
| 塑料      | ○         | ○     | ○     | ○         | ○         | ○           |
| 金屬      | ×         | ○     | ○     | ○         | ○         | ○           |
| 電池      | ×         | ○     | ○     | ○         | ○         | ○           |
| 配件      | ×         | ○     | ○     | ○         | ○         | ○           |

本表格依據SJ/T11364的規定編制。

○:表示該有害物質在該部件所有均質材料中的含量均在GB/T26572規定的限量要求以下。

×:表示該有害物質至少在該部件的某一均質材料中的含量超出GB/T26572規定的限量要求。



## 提 示

- 1.使用產品前請仔細閱讀本用戶手冊並請妥善保管；
- 2.首次使用,請先將本產品充滿電；
- 3.如果產品長期(超過1個月)不使用,請對其充電；
- 4.必須選擇正規廠家生產的經過第三方權威機構認證的充電線和電源適配器。

## 警 告


- 1.請勿以任何理由拆除、維修和改裝耳機,否則可能會導致起火、電子擊穿甚至徹底損壞本產品；
- 2.請勿將設備置於溫度過低或過高(-10°C以下或50°C以上)的環境中；
- 3.請勿在雷暴天氣下使用該設備,雷暴可導致設備工作不正常,並增加觸電的危險；
- 4.請勿用油及其它揮發性液體擦拭本產品；
- 5.本產品內含鋰電池,禁止拆解、撞擊、擠壓或投入火中。若出現鼓脹,請勿使用。

# 合格證


本產品  
經檢驗合格准予出廠

# PRODUCT INFORMATION


Model: LONDON S



# LET'S GET STARTED



Power indicator




Charging port

On / Off



## FIRST TIME PAIRING



If there is no connection, it will automatically turn off after 10 minutes.  
If there is no operation in the bluetooth connection state, it will automatically turn off after 30 minutes.

Left




Right



When two speakers of the same model are power on, press the **bluetooth** button of one speaker first, and then press the **bluetooth** button of the other speaker twice. There will be a beep at the same time while two speakers are connected to each other.


## OPERATION



Disconnected




Clear connection




(Beep beep beep)  
The LED flashes thrice.


## Cancel dialing/Hang up/Answer call



## Reject call




## AUX MODE



## LED INDICATOR

The LED is red during charging and turns white while fully charged.




## FEATURES

---

### Waterproof IPX7



### Stereo audio



Use two speakers separately or together.

## BATTERY

---



Low battery warning: The LED blinks every 60s, and an audible warning occurs every 5 minutes.




Please charge it as soon as possible, otherwise it will turn off automatically.

## TOTAL PLAYTIME

At average use for music at 50% volume.



### Recharging



## Guarantee card

Thank you for choosing LANGEHREN True bluetooth speaker. Since the date of your purchase of the product, if it is not artificially damaged, our company will provide return within 7 days, exchange within 15 days, free maintenance services within one year.

### ● Service item:

1. Within 7 days from the date of receipt, if you need to return the goods, ensure that the goods received are in good condition, the product packaging and accessories are complete, no artificial damage performance and appearance damage, one-time refund, or replace the same model and specifications of the product according to the purchase record. (7 days without reason to return, buyers need to bear the freight)
2. Within 8 to 15 days from the date of receipt, no artificial damage performance and appearance damage, replace the same model and specifications of the product according to the purchase record.
3. Within one year guarantee period, if the product appears the fault not artificially damaged, the user can get free repair in touch with seller by this warranty card and purchase voucher.

### ● The following conditions do not belong to the service contents of the Packages Policy:

1. Damage caused by self-disassembly.
2. Due to falling damage, soaking, collision damage and other human factors
3. Within one year guarantee period, if the product appears the fault not artificially damaged, the user can get free repair in touch with seller by this guarantee card and shopping proof.
4. No warranty card, no purchase voucher and intentional modification voucher
5. Fault or damage caused due to force majeure.

### ● Product information:

|                  |  |                |  |
|------------------|--|----------------|--|
| Product Name     |  | Machine Type   |  |
| Product Code     |  | Product Number |  |
| Purchase Voucher |  | voucher Number |  |
| Purchase Date    |  | Receipt Date   |  |
| User Name        |  | Phone Number   |  |
| Seller           |  |                |  |
| Seller Contact   |  | Phone Number   |  |

More services can be found at LANGEHREN's official website: [www.langehren.cn](http://www.langehren.cn)

## LIST OF TOXIC AND HARMFUL SUBSTANCES IN ELECTRONIC INFORMATION PRODUCTS

| TYPE        | Toxic or harmful substance or elements |    |    |      |     |      |
|-------------|----------------------------------------|----|----|------|-----|------|
|             | Pb                                     | Hg | Cd | Cr6+ | PBB | PBDE |
| PCBA        | ×                                      | ○  | ○  | ○    | ○   | ○    |
| Plastic     | ○                                      | ○  | ○  | ○    | ○   | ○    |
| Metal       | ×                                      | ○  | ○  | ○    | ○   | ○    |
| Battery     | ×                                      | ○  | ○  | ○    | ○   | ○    |
| Accessories | ×                                      | ○  | ○  | ○    | ○   | ○    |

This form is based on the provisions of SJ/T11364 establishment.

○ : it means the harmful substances in the parts of homogeneous material content all exceed limited requirements of GB/T26572 regulations.

×

it means the harmful substances in the parts of at least one homogeneous material beyond limited requirement.



## Caution

1. Please read this user manual carefully before using the product and safe keeping.
2. For first use, please fully charge the product;
3. If the product is not used for a long time (more than 3 months), please charge it.
4. It is necessary to use the charging cable and power adapter produced by a formal manufacturer and certified by a third party authority.

## Warning

1. Do not remove or repair modified sound box for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.
2. Do not place the product in an environment where the temperature is too low or too high (below -10° C or above 50° C)
3. Do not use the product during thunderstorms.  
Thunderstorms may cause abnormal operation of the product and increase the risk of electric shock.
4. Do not wipe the product with oil or other volatile liquids;
5. This product contains lithium battery, do not disassemble, impact, squeeze or put into fire. Do not use if there is swelling.  
Do not expose to high temperature.

QUALITY CERTIFICATE

Q.C.  
PASSED